EEG Motor Movement/Imagery Dataset

Published: Sept. 9, 2009. Version: 1.0.0

When using this resource, please cite the original publication:

Schalk, G., McFarland, D.J., Hinterberger, T., Birbaumer, N., Wolpaw, J.R. BCI2000: A General-Purpose Brain-Computer Interface (BCI) System. IEEE Transactions on Biomedical Engineering 51(6):1034-1043, 2004.

Please include the standard citation for PhysioNet: Goldberger AL, Amaral LAN, Glass L, Hausdorff JM, Ivanov PCh, Mark RG, Mietus JE, Moody GB,

This data set consists of over 1500 one- and two-minute EEG recordings, obtained from 109 volunteers, as described below.

Experimental Protocol

Subjects performed different motor/imagery tasks while 64-channel EEG were recorded using the BCI2000 system (http://www.bci2000.org). Each subject performed 14 experimental runs: two one-

minute baseline runs (one with eyes open, one with eyes closed), and three two-minute runs of each of the four following tasks: 1. A target appears on either the left or the right side of the screen. The subject opens and closes the corresponding fist until the target disappears. Then the subject relaxes. 2. A target appears on either the left or the right side of the screen. The subject imagines opening

and closing the corresponding fist until the target disappears. Then the subject relaxes. 3. A target appears on either the top or the bottom of the screen. The subject opens and closes either both fists (if the target is on top) or both feet (if the target is on the bottom) until the

- target disappears. Then the subject relaxes. 4. A target appears on either the top or the bottom of the screen. The subject imagines opening
- and closing either both fists (if the target is on top) or both feet (if the target is on the bottom) until the target disappears. Then the subject relaxes.
- In summary, the experimental runs were:
 - 2. Baseline, eyes closed 3. Task 1 (open and close left or right fist) 4. Task 2 (imagine opening and closing left or right fist)

6. Task 4 (imagine opening and closing both fists or both feet)

- 9. Task 3
- 11. Task 1
- 12. Task 2
- 14. Task 4
- files and the annotation channels in the corresponding .edf files contain identical data.
- T1 corresponds to onset of motion (real or imagined) of o the left fist (in runs 3, 4, 7, 8, 11, and 12)

o both fists (in runs 5, 6, 9, 10, 13, and 14) • T2 corresponds to onset of motion (real or imagined) of o the right fist (in runs 3, 4, 7, 8, 11, and 12) o both feet (in runs 5, 6, 9, 10, 13, and 14)

In the BCI2000-format versions of these files, which may be available from the contributors of this data

Each annotation includes one of three codes (T0, T1, or T2):

Acknowledgments

- The EEGs were recorded from 64 electrodes as per the international 10-10 system (excluding
- numbers below each electrode name indicate the order in which they appear in the records; note that signals in the records are numbered from 0 to 63, while the numbers in the figure range from 1 to 64.

org) and his colleagues at the BCI R&D Program, Wadsworth Center, New York State Department of Health, Albany, NY. W.A. Sarnacki collected the data. Aditya Joshi compiled the dataset and prepared

This data set was created and contributed to PhysioBank by Gerwin Schalk (schalk at wadsworth dot

Files

Folder Navigation: <base>

- **S**003
- **S005**
- **S**010
- **S**011
- **S**012 **S**013
- **S**015
- **S**017
- **S**019 **S**020
- **S**022 **S**023
- **S**024 **S**025
- **S**027 **S**028
- **S**029 **S**030
- **S**031 **S**032
- **S**034 **S**035
- **S**037 **S**038
- **S** S039 **S**040
- **S**042
- **S**043 **S**044
- **S** 5046 **S**047
- **S**050 **S**051
- **S**055 **S**056

S057

S \$060 **S** 5061

S S062

- **S** S063 **S** 5064 **S** S065
- **S** S069 **S**070
- **S**074 **S**075
- **S**077 **S**078 **S**079

S080

S 5081

- **S** 5082 **S** \$083
- **S** S086 **S** S087

S \$088

- **S**091
- **S**095 **S** S096
- **S**098 **S**099

S S097

- **S**104
- **S**109

- 1. Baseline, eyes open
 - 7. Task 1 8. Task 2
 - 13. Task 3
- Montage electrodes Nz, F9, F10, FT9, FT10, A1, A2, TP9, TP10, P9, and P10), as shown in this PDF figure. The
- the documentation. D.J. McFarland and J.R. Wolpaw were responsible for experimental design and project oversight, respectively. This work was supported by grants from NIH/NIBIB ((EB006356 (GS) and EB00856 (JRW and GS)).

✓ Visualize waveforms

- **S** 5004
- **S** 5009
- **S**014
- **S**016

- **S**033

- **S**045
- **S**049
- **S**054
- **S**059
- **S** S066
- **S** 5071 **S** 5072 **S**073

- **S** 5089 **S**090
- **S100**
- **S**105
- **S** 5106 **S107 S108**
- 64_channel_sharbrough.png **ANNOTATORS** RECORDS SHA256SUMS.txt

- 5. Task 3 (open and close both fists or both feet)
 - 10. Task 4
- The data are provided here in EDF+ format (containing 64 EEG signals, each sampled at 160 samples per second, and an annotation channel). For use with PhysioToolkit software, rdedfann generated a separate PhysioBank-compatible annotation file (with the suffix .event) for each recording. The .event

• **T0** corresponds to rest

- set, these annotations are encoded as values of 0, 1, or 2 in the TargetCode state variable.
- Total uncompressed size: 3.4 GB. Access the files Download the ZIP file (1.9 GB)
- Name **S**001

S002

- **S** 5006 **S007 S008**
- **S**018
- **S**021
- **S**026
- **S**036
- **S** 5041
- **S** 5048
- **S**052 **S**053
- **S**058
- **S** S067 **S** S068
- **S** 5076
- **S** 5084 **S** \$085
- **S**092 **S**093 **S**094
- **S**101 **S**102 **S**103
- 64_channel_sharbrough-old.png 64_channel_sharbrough.pdf
- wfdbcal

- **Abstract**
- Peng C-K, Stanley HE. PhysioBank, PhysioToolkit, and PhysioNet: Components of a New Research Resource for Complex Physiologic Signals (2003). Circulation. 101(23):e215-e220.

Access

Share

Topics:

information.

Access Policy:

Q

Anyone can access the files, as long as they

conform to the terms of the specified

license.

License (for files): Open Data Commons Attribution License v1.0

Discovery DOI: https://doi.org/10.13026/C28G6P

movement neuroelectric

Corresponding Author

You must be logged in to view the contact

• Access the files using the Google Cloud Storage Browser here. Login with a Google account is required. • Access the data using Google Cloud "gsutil": gsutil -m cp -r gs://eegmmidb-1.0.0.physionet.org DESTINATION • Download the files using your terminal: wget -r -N -c -np https://physionet.org/files/eegmmidb/1.0.0/ **Modified** Size

56.1 KB 2009-08-28

2015-08-19 61.8 KB 24 B 2009-08-28 25.3 KB 2016-04-19 253.8 KB 2019-02-20 1.6 KB 2009-08-06

16.9 KB

2009-08-28

PhysioNet is a repository of freely-available medical research data, managed by the MIT Laboratory for Computational Physiology 🗗.

Supported by the National Institute of General Medical Sciences (NIGMS) 🖶 and the National Institute of Biomedical Imaging and Bioengineering (NIBIB) 🗗